




WALL HANG URINAL

Installation Instruction

Petunjuk Pemasangan

INSTALLATION INSTRUCTION

Installation Instruction of Wall Hang Urinal

1. Before installation, the wall and floor tiles should have been completed, and the pit and water supply lines are reserved.
2. The distance between the center of the pipe and the wall should be in line with the distance from the pits of the toilet.

Installation Steps

1. PREPARATION
 - Turn the water supply OFF.
 - Install or relocate the supply tubing and waste pipe as necessary to conform to the roughing in dimensions.
 - Install the shut off valve.
 - Install adequate support framing for the wall hangers as needed.
 - Determine the position of the waste pipe nipple. When establishing the nipple length, take into account the length of the urinal outlet spud and the distance of the female collar will thread onto the waste pipe nipple.

NOTE: Add a little extra length to the nipple to allow for gasket space.

* This installation instruction is suitable for HU 03, HU 04, HU 05, HU 06, HU 07 and HU 08.


2. INSTALLATION

- Install the wall hangers according to the roughing in illustration.
- Apply thread sealant tape to the pipe threads and install the female collar to the waste pipe.
- Place the gasket onto the female collar with the beveled surface facing away from the collar.
- Carefully position the urinal on the wall hangers.
- Secure the urinal to the female collar using the screws and washers provided.


CAUTION:

RISK OF PERSONAL INJURY OR PRODUCT DAMAGE. HANDLE WITH CARE.
RISK OF PRODUCT DAMAGE. DO NOT OVERTIGHTEN THE BOLTS.


- Install the flush valve according to the instructions.
- Connect the water supply and complete the waste pipe connections.
- Turn on the water supply.
- Flush and check the entire installation for leaks.




* This illustration below is for wall hang urinal with top inlet manual flush.



* This illustration below is for wall hang urinal with back inlet sensor flush.
More information can be found on Sensor Urinal Flush Manual Instruction



* This illustration below is for wall hang urinal with top inlet sensor flush.
More information can be found on Sensor Urinal Flush Manual Instruction



Cleaning & Maintenance



To keep the product clean & shining, follow the steps as below:

- Flush with clean water & dry with soft cloth only.
- If any dirt, clean with soft liquid or transparent glass detergent.
- Do not use any scrubbing detergent, polisher, sane-cloth, paper tissue or scraper.
- Do not use acid detergent, indissolvable grain-like detergent or soap.

PETUNJUK PEMASANGAN

Petunjuk Pemasangan Urinoir Gantung

1. Sebelum pemasangan, pastikan dinding toilet, lantai keramik, lubang, dan jalur pasokan air telah siap.
2. Jarak antara tengah pipa dengan tembok harus sesuai dengan jarak dari lubang toilet.

Langkah-Langkah Pemasangan

1. PERSIAPAN
 - Matikan saluran air.
 - Pasang/pindahkan tabung pasokan air dan pipa pembuangan untuk keperluan penyesuaian dimensi yang ada.
 - Pasang katup penutup.
 - Pasang rangka yang sesuai untuk kebutuhan gantungan dinding.
 - Tentukan posisi nepple pembuangan air. Ketika menyesuaikan panjang nepple, perhatikan panjang dari pipa sambungan yang akan dipasangkan pada pipa pembuangan air.

CATATAN: Tambahkan sedikit panjang pada nepple untuk ruang pada gasket.

* Instruksi pemasangan ini dapat diaplikasikan untuk HU 03, HU 04, HU 05, HU 06, HU 07 dan HU 08.


2. PEMASANGAN

- Pasang rangka urinoir pada dinding sesuai dengan instruksi kasar pada ilustrasi.
- Aplikasikan plester pada pipa dan pasangkan pipa drat luar pada pipa pembuangan air.
- Posisikan gasket pada pipa drat luar dengan posisi bertolak belakang dari drat luar.
- Dengan hati-hati pasangkan urinoir pada rangka dinding.
- Eratkan urinoir pada pipa drat luar dengan menggunakan skrup dan cincin penutup yang disediakan.


PERHATIAN:

RESIKO CEDERA PRIBADI DAN KERUSAKAN PRODUK. TANGANI DENGAN HATI-HATI. JANGAN TERLALU MENGENCANGKAN BAUT.


- Pasang katup flush sesuai dengan instruksi
- Sambungkan saluran air dan selesaikan sambungan pipa pembuangan air
- Nyalakan saluran air
- Flush dan cek keseluruhan pemasangan, apakah terjadi kebocoran atau tidak




* Ilustrasi dibawah ini berlaku untuk urinoir gantung dengan *top inlet manual flush*.



* Ilustrasi dibawah ini berlaku untuk urinoir gantung dengan *back inlet sensor flush*.
Untuk informasi lebih lanjut dapat dilihat pada petunjuk pemasangan *sensor urinal flush*.



* Ilustrasi dibawah ini berlaku untuk urinoir dengan *top inlet sensor flush*.
Untuk informasi lebih lanjut dapat dilihat pada petunjuk pemasangan *sensor urinal flush*.



Pembersihan & Perawatan



Untuk menjaga produk tetap bersih dan mengkilap, ikuti langkah-langkah di bawah ini:

- o Siram dengan air bersih dan keringkan dengan kain lap yang lembut.
- o Jika terdapat kotoran, bersihkan dengan cairan yang tidak keras atau dengan deterjen kaca transparan.
- o Jangan menggunakan deterjen gosok, penggosok, kertas tisu, atau pengikis/pengikir.
- o Jangan menggunakan butiran dengan zat kimia yang sulit larut seperti deterjen dan sabun.



www.aer.co.id