


WALL HUNG TOILET


Installation Instruction

Petunjuk Pemasangan


INSTALLATION GUIDE




1. Adjust the iron bracket according to the height and fix it.



2. Fix the iron bracket to the ground.




3. Insert baffle into plastic adjusting lever and tighten with screw.





4. Adjust the distance between the plastic screw and the baffle.

* This installation instruction is suitable for HWC 08, HWC 09 and HWC 10




5. Fix the panel to the bulkhead.




6. Adjust the length of the long screw to expose the iron support according to the thickness of the wall and fix the screw on the iron support with a nut.



7. The thickness of the wall determines the length of the small straight pipe and the big straight pipe.



8. The small straight pipe and the big straight pipe respectively fixed in the toilet.




9. Insert the toilet with the small and big straight pipe into the screw rod and fix it according to the arrow direction.


PETUNJUK PEMASANGAN




1. Pasang braket besi, sesuaikan dengan ketinggian dinding.



2. Pasang braket besi ke permukaan tanah.




3. Masukkan baffle ke plastik skrup dan kencangkan dengan skrup.





4. Sesuaikan jarak antara plastik skrup dan baffle.

* Instruksi pemasangan ini dapat diaplikasikan untuk HWC 08, HWC 09 dan HWC 10




5. Pasang panel pada sekat.




6. Sesuaikan panjang skrup pada besi penyangga dengan ketebalan dinding, setelah itu kencangkan skrup pada besi penyangga dengan menggunakan nut.



7. Ketebalan dinding menentukan panjang dari pipa lurus kecil dan pipa lurus besar.



8. Pasang pipa lurus kecil dan pipa lurus besar pada masing-masing lubang yang sesuai pada toilet.



9. Masukkan toilet beserta dengan pipa lurus kecil dan pipa lurus besar ke batang skrup dan pasangkan sesuai dengan arah panah.



www.aer.co.id